


CITO LOCK - operation manual


The CITO LOCK principle works only in combination with the special CITO LOCK Nut. The CITO LOCK material and geometry are perfectly aligned, so the bolt optimally dovetails with the thread to create the perfect CITO LOCK locking function.

1. Cut the CITO LOCK notch into the upper and lower Stripping Board
For correct positioning of the CITO LOCK the notches have to lie on top of each other!

CAD-Template: [CITO LOCK notch \(end of page\)](#)



2. Mount the correct CITO LOCK Nut into the upper Stripping Board.



3. Install the CITO LOCK Bolt through the notch in the lower Stripping Board and screw the bolt clockwise.

